

800.551.3569 TOLL FREE USA & CANADA 501.374.7416 TEL 501.376.7147 FAX www.GlobalManufacturing.com



	Table of Contents	Page
Ι.	Introduction	
	What is an Air Blaster and Applications	3
	Safety Precautions	4
II.	Air Blaster Operation	
	General overview - How the Air Blaster works	5
	Air requirements and Air Filtration	5
	Lubrication	5
	When to "fire" the Air Blaster	5
	Methods of control - Manual versus Automatic operation	6
	Use of a quick exhaust valve	6
	Required accessories	6 - 7
	Test firing the Air Blaster	7
III.	Installation	
	Preparation and background	7 - 11
	Visual inspection	11
	Temporary plug removal	11
	Installing discharge pipe	11 - 14
	Mounting the Air Blaster to the discharge pipe	12 - 13
	General piping instructions for Air Blaster System air control components	14
	Air Blaster control components installation	15 -18
IV.	Air Blaster Start-Up Procedures	19
V.	Maintenance	19
VI.	Disassembly And Assembly Of The Air Blaster	
	Dismounting the Air Blaster	20
	Removing the internal valve	20 - 21
	Valve disassembly and inspection	21
	Assembling the valve	22
	Assembling the Air Blaster	22
	Testing the Air Blaster	23
Appendix A	Troubleshooting	24
Appendix B	System Spare Parts Recommendations	25
Appendix C	Air Blaster dimensions	26
Appendix D	Air Blaster plumbing diagrams	27
Appendix E	Air Blaster performance data	28
Appendix F	Air Blaster parts drawings	29 - 31
Appendix G	Coordinates & Dimensions of elliptical openings for tangential mounts	32

Global Manufacturing, Inc ®
1801 East 22nd Street
Little Rock, AR 72206 USA



I. Introduction

This manual will assist in the installation and operation of Global GW Series direct blast Air Blasters. Please read the entire manual to assure proper installation, operation, and maintenance of this equipment. These instructions apply to the following models:

GW2.5-8-24:2.5" discharge8" x 24" tank20LGW4.0-12-28:4" discharge12" x 28" tank50LGW4.0-16-34:4" discharge16" x 34" tank100LGW4.0-20-30:4" discharge20" x 30" tank150LGW6.0-24-48:6" discharge24" x 48" tank300LGW6.0-30-60:6" discharge30" x 60" tank650L



What is an Air Blaster?

Global Air Blasters are direct blast aerators consisting of a compressed air reservoir with a quick opening valve that releases the stored air in a sudden, high energy blast. This blast is directed through a discharge pipe to restore material flow by aerating and dislodging material that is bridging, arching, rat holing, or clinging.



The direct blast design allows the stored air in the reservoir to escape directly into the discharge pipe without bends or obstructions that could impede the flow of air. This is important because the quicker the air discharges, the greater the velocity and force of the blast and, therefore, the greater the amount of material affected. Air Blasters are activated manually or by a micro-controller based sequencing timer which controls the firing time interval and sequence of one or more Air Blasters. Global Manufacturing offers two lines of direct blast aerators, the GW and GWE Series for general use (ambient temperatures below 130°F/55°C) and the G400 Series for high temperature applications (ambient temperatures up to 400°F/200°C) such as cement kilns and steel mills where internal kiln temperatures can be as high as 2,000°F or 1,100°C (mounting instructions must be strictly followed for high temp applications). We also have a subzero model available.

Applications:

Air Blasters easily solve bulk flow problems in silos, hoppers, chutes, and storage piles. They are used where vibration is not practical, or when other methods are too expensive, dangerous, or destructive. Air Blasters are recommended for a wide range of material clogs and jams and are well suited for large structures of any type. They are commonly used when it is impractical to vibrate stuck material loose and are effective for very cohesive, difficult materials. For instance, large concrete bunkers and storage piles on the ground are impossible to vibrate, but are common locations of flow problems. Wood chips are very difficult to dislodge by other means, but respond very well to the quick-release Air Blaster. Air Blasters are also used to periodically aerate material sitting in bins, hoppers, and silos.



SAFETY PRECAUTIONS

The air blast can exceed 1,000 ft/sec (300 m/sec) and 1,500 lb (680 kg) of force. Be sure to read and follow all safety precautions.

DANGER!

- ♦ Do not stand in front of any Air Blaster during discharge. The air blast can cause serious injury.
- ♦ Use of an Air Blaster to shoot a projectile may cause serious injury or death.

T

WARNING!

- ♦ Global Air Blaster pressure vessels are ASME code welded and certified. Do not weld onto the pressure vessel (tank). Welding to the tank will void ASME certification and may cause vessel malfunction.
- ♦ All OSHA, ANSI and owner's safety procedures and regulations must be followed during installation, operation, and maintenance of Air Blasters.
- Do not discharge Air Blaster into open air without clear warnings to all persons in the area.
- All Air Blasters must be empty of air when being transported, mounted, or inspected.
- Due to recoil, do not discharge an Air Blaster that is not securely mounted to a structure.
- Mount Air Blaster securely on Schedule 40 pipe or equivalent. If the structure is not sufficiently rigid to support the Air Blaster, obtain special mount hardware from your distributor.
- Attach the ring on the end of the Air Blaster tank to a structural support with a safety cable to prevent the Air Blaster from falling if its supports were to give way.
- ♦ Do not enter application structure (i.e. bin or hopper) if Air Blasters are pressurized and ready to be discharged.

Caution!

- Do not allow the internal pressure in a closed storage vessel to exceed its limitations when the Air Blasters are fired. This may cause damage to the storage vessel. Install exhaust vents if pressures exceed 0.5 psi (0.034 bar). The momentary vessel pressure following the firing of an Air Blaster can be estimated as follows:
- $P_m = Air Blaster tank pressure (psi or atm) x Air Blaster tank volume (ft³ or liters)$ Air Blaster tank volume (ft³ or liters) + Structure volume (ft³ or liters)



II. Air Blaster Operation

General Overview—How the Air Blaster Works:

Each Blaster is charged with compressed air through an air inlet controlled by a 3-way normally open valve (either a manual valve or a solenoid valve). Once filled, the Air Blaster remains charged as long as pressure to the tank is maintained by pressure in the fill line. To fire the Air Blaster, pressure in the fill line is suddenly reduced by switching the 3-way valve, evacuating the air in the fill line to the atmosphere. After firing, re-switching the 3-way valve will restore plant air allowing the Air Blaster to refill. A stepby-step outline of the filling and discharging process follows:

- A 3-way valve in the open position allows plant air to enter the Air Blaster. The pressure of the plant air insures an air tight seal between the piston and seat, preventing any air loss while Air Blaster is waiting to be fired.
- 2. Plant air is forced out through the check valve in the valve cap to fill the pressure vessel with air.
- 3. Once filled, the Air Blaster remains on standby waiting to be fired.
- 4. When the 3-way valve is switched, air in the fill line is exhausted, causing the air pressure at the back of the piston to drop.
- 5. Due to the pressure differential created, the tank pressure forces the piston back into the open position.
- 6. The compressed air in the pressure vessel escapes through the discharge in an explosive blast that lifts and separates material particles, restoring material flow.
- 7. The 3-way valve is re-switched allowing the plant air to recharge the Air Blaster.
- The pressure of the plant air forces the piston 8. to close against the valve seat preventing contaminants from entering the Air Blaster.



Air Requirements:

For optimum performance, operate the Air Blaster on filtered, regulated air between 45 and 125 psi (3 - 8.6 bar). The pressure may be adjusted to obtain the desired amount of blast force (generally 80-100 psi). Refer to the performance data in Appendix E to see how the blast force varies with air pressure and to determine the quantity of air needed to fill the Air Blaster for each pressure level. Use a standard air compressor, however, nitrogen, carbon dioxide or another inert gas can be used in place of the normal air supply. The Air Blaster pressure vessel has a 125 psi pressure relief valve (safety valve) and will completely exhaust the compressed air inside the tank without firing the Air Blaster if the ring is pulled (see page 20).

Air Filtration:

Use filtered (40 Micron) compressed air to fill and operate the Air Blaster.

Lubrication:

Global Air Blasters require no lubrication.

When to "Fire" the Air Blaster:

It is best to discharge the Air Blaster only when a material flow problem occurs. Firing too often when the storage vessel discharge is closed is not recommended. A group of Air Blasters may be fired sequentially using the Global Blaster Master micro-controller based sequencing timer.



Methods of Control - Manual versus Automatic Operation:

Control a Global Air Blaster System either manually or automatically:

Manual Operation: For strictly manual operation the Air Blaster is controlled by a **3-way** normally open manual valve. This type of valve has 3 ports - an inlet to connect to the air source, an outlet to connect to the Air Blaster, and an exhaust port. A 34" valve is used for the GW2.5-8-24, GW4.0-12-28, GW4.0-16-34, and GW4.0-20-30 models, and a 1" valve is used for the GW6.0-24-48 and GW6.0-30-60 models. The manual 3-way valve is placed in the "open" position to fill the Air Blaster and to keep it pressurized in a standby, ready-tofire mode. To discharge the Air Blaster, the valve is moved to the "closed" position, which exhausts the air in the fill line between the valve and the Air Blaster. This sudden decrease in line pressure fires the Air Blaster. The valve should be returned to the "open" position to refill the Air Blaster for its next use. If manual operation is desired, but the manual valve will be placed more than 10 feet (3 m) from the Air Blaster or will be smaller than the **size recommended** above, use a quick exhaust valve with the manual valve to ensure optimum performance of the Air Blaster (see "Use of a Quick Exhaust Valve" below).

Automatic Operation: For automatic operation the Air Blaster is controlled by a **3-way normally** open solenoid valve. It has 3 ports - an inlet to connect to the air source, an outlet to connect to the Air Blaster, and an exhaust port. A 3/4" Solenoid is used for the GW2.5-8-24, GW4.0-12-28, GW4.0-16-34, and GW4.0-20-30 models, and a 1" solenoid is used for the GW6.0-24-48 and GW6.0-30-60 models. The solenoid is controlled electronically using a Global Blaster Master timer or a manually triggered momentary electric switch. When not energized, the solenoid valve is "open", allowing the Air Blaster to fill with air. The Air Blaster will remain pressurized in a standby, ready-to-fire mode as long as the solenoid valve is open. To discharge the Air Blaster, the solenoid is energized by the timer or switch closure. This closes the solenoid valve, which exhausts the air in the fill line between the solenoid and the Air Blaster. This sudden decrease in line pressure fires the Air Blaster. The timer or opening of the switch de-energizes the solenoid, the valve re-opens and the Air Blaster is re-filled for its next use. If automatic operation is desired, but the solenoid valve will be placed more than 10 feet from the Air Blaster or will be smaller than the

size recommended above, use a quick exhaust valve with the solenoid valve to ensure optimum performance of the Air Blaster (see "Use of a Quick Exhaust Valve" below).

Use of a Quick Exhaust Valve:

The Air Blaster is discharged by reducing the pressure in the internal valve assembly. The quicker the pressure drop occurs, the faster the Air Blaster piston opens, therefore the faster and more forceful the air blast. To obtain optimum Air Blaster performance (maximize the force for the air pressure being used), the device used for exhausting the fill line needs to be as close to the Air Blaster as possible. Mount the 3-way normally open valve (manual or solenoid) used to discharge the Air Blaster directly to the air inlet port on the Air Blaster pressure vessel. The further the valve is located from the Air Blaster, the more the blast will be degraded. If the valve (manual or solenoid) is located more than 10 feet (3 m) from the Air Blaster, mount a quick exhaust valve to the air inlet port of the Air Blaster pressure vessel. The quick exhaust valve is actuated by the 3-way valve and will quickly reduce the air pressure in the internal valve, resulting in maximum Air Blaster performance. Use a ³/₄" quick exhaust valve for the GW2.5-8-24 model and a 1" or larger quick exhaust valve for all other models.

NOTE Using the recommended quick exhaust valve mounted on the Air Blaster air inlet port will ensure optimum performance of your Global Air Blaster.

Required Accessories:

This manual includes instructions for installing a complete Air Blaster system. The following air control components are necessary for Global GW Series Air Blasters to be fully operational. They are available from Global Manufacturing and your Global distributor:

1. **Shut-off Ball Valve:** A 2-way shut-off ball valve is used to isolate the Air Blaster system from the plant air supply. Install it between the plant air supply and all other components in the Air Blaster system. Clearly label and locate the shut-off valve where it can be quickly and easily reached in an emergency or for routine maintenance. Use one shut-off valve for each filter-regulator-gauge used in the system. A ¹/₂" or larger valve is recommended for all Air Blaster models.

800.551.3569 TOLL FREE USA & CANADA 501.374.7416 TEL 501.376.7147 FAX www.GlobalManufacturing.com



2. **Filter-Regulator-Gauge:** The filterregulator-gauge (FRG) protects the Air Blaster and airline components by filtering water and particulate contaminants from the air supply. It also is used to control the force output of the Air Blaster by regulating the air pressure (determines the volume of air stored in the Air Blaster pressure vessel). For optimum performance drain the filter reservoir of the FRG daily. For this reason, an FRG that drains automatically may be desired. We recommend using one (1) FRG for every four (4) Air Blasters. A ¹/₂" or larger FRG is recommended for all Air Blaster models.

3. **Airline Check Valve:** The airline check valve prevents accidental firing of the Air Blaster due to pressure loss in the main supply line. If the main airline loses pressure, the check valve maintains pressure to the Air Blaster by preventing backward air flow. Use one check valve for every Air Blaster, and install it between the FRG and the 3-way control valve. A $\frac{1}{2}$ " or larger check valve is recommended for all Air Blaster models.

4. **3-Way Control Valve:** The 3-way control valve controls the firing of the Air Blaster. When in the open position, the Air Blaster is filled with air and maintained in the standby, ready-to-fire mode. When closed, the Air Blaster is discharged. A ³/₄" control valve can be used and located up to 100 feet (30 m) from the Air Blaster for all models **when the recommended quick exhaust valve is also used** (see below). For manual firing only, use a manual valve. For automatic firing, use a solenoid valve. When no quick exhaust valve is used, it is recommended the 3-way normally open valve be placed within 10 feet (3 m) of the Air Blaster. Increase the size of the valve to 1" for the GW6.0-24-48 and GW6.0-30-60 models.

5. **Quick Exhaust Valve:** For optimum Air Blaster performance, place a quick exhaust valve (QEV) in the supply airline, at the Air Blaster pressure vessel air inlet port. This valve ensures the rapid depressurization of the Air Blaster valve necessary to fire the Air Blaster and produce maximum blast force. When using a QEV, the 3-way normally open valve (manual or solenoid) can be placed up to 100 feet (30 m) from the Air Blaster without any substantial loss of blast performance. A 3/4" QEV is recommended for the GW2.5-8-24 model and a 1" or larger QEV is recommended for all other models.

Test Firing the Air Blaster:

Before mounting the Air Blaster to the discharge pipe for the first time (or before remounting after servicing the Air Blaster valve), do a test firing. During tests, place the Air Blaster on its side with the end opposite the discharge opening adequately supported to withstand the recoil that occurs when the Air Blaster is fired. The pressure relief valve must be in place. Minimum pressure for testing is 40 psi (3.1 bar)

WARNING!

Because of the hazards associated with the force of the blast and the recoil, do not fill the Air Blaster pressure vessel beyond 60 psi (4.1 bar) for testing purposes. Minimum pressure for testing is 40 psi (3.1 bar).

Warn Personnel in the testing area to stay way from the Air Blaster discharge outlet. The air blast can cause serious injury.

Wear eye and ear protection. Air Blasters produce a very loud noise when discharged in open space.

III. Installation

Preparation and Background:

Air Blaster Placement: To be sure Air Blasters provide the greatest effect, it is important to properly locate them on the storage structure. The placement and quantity of Air Blasters depends on several factors.

1. **Shape of the storage structure:** In general, square structures require more Air Blasters than round structures because materials tend to hang up in the corners. Be sure the Air Blasters will reach all major problem areas such as corners and the base of any known or suspected areas of bridging, arching, rat holing, or clinging.

2. **The degree of material flow desired:** If Air Blasters are used to constantly move or aerate the material, or if the sides of the storage structure must be kept very clean, more Air Blasters will be needed than if they are only used to restore material flow after a stoppage.

3. **Properties of the bulk material:** Each Air Blaster has an approximate "area of influence" which varies with the properties of the bulk material. As a rule of thumb, for Air Blaster applications, bulk materials are grouped into the two categories described as Type I or Type II (page 8).

4. **Additional Guidelines:** If the discharge pipe will be longer than 6 feet (1.8 meters) in length, it is recommended that the next larger size Air Blaster be used.



Area-of-Influence

Use the following charts and diagrams to assist in determining the number and placement of the Air Blasters. For best coverage, make sure the areas of influence of the Air Blasters overlap.

NOTE If your bulk material has two or more of the properties listed for Type I, consider it a Type I Material. If it has none or only one of the properties for Type I, but has several Type II properties, consider it a Type II Material.



Type I Material

Stored in structure with low sloping walls Stored in structure with small discharge outlet Density in excess of 55 lb/ft³ (880 kg/m³) Clings, regardless of weight Compacts easily Greasy or pasty consistency "Sets up" or hardens during holding Large chunks or mixed size Heavily oil- or water-laden

Type II Material

Stored in structure with high sloping walls Stored in structure with large discharge outlet Density less than 55 lb/ft³ (880 kg/m³) Does not cling Spongy and does not compact Dry or powdery Flows easily under most conditions

NOTE

The Area of Influence data is based on filling the Air Blaster at 90 p.s.i. (6.2 bar).

800.551.3569 TOLL FREE USA & CANADA 501.374.7416 TEL 501.376.7147 FAX www.GlobalManufacturing.com



		ſ	Number of Air Blasters Recommended per Bin/Hopper								Are	ea of			
Air Blaster	Material		Diameter of Structure Influenc										lence		
Model	Туре	ft	3	5	10	15	20	25	30	35	40	45	50	ft	m
		m	1	1.5	3	4.5	6	8	9	10.6	12	14	15		
2.5" Discharg	je														
	I		1	3	6	9	12	15	18	21	24	27	30	4	1.2
GW2.5-6-24	II		1	2	3	5	6	7	8	10	12	13	15	7	2.1
4" Discharge															
CW/4 12 29	I		*	3	4	6	10	12	14	16	18	20	25	5	1.5
GW4-12-20	II		*	2	3	4	5	6	7	8	10	11	12	8	2.4
CW/4 16 24	I		*	2	3	6	9	11	13	14	17	18	22	6	1.8
GW4-10-54	II		*	1	2	3	4	5	6	7	8	9	11	9	2.7
CW4 20 20	Ι		*	2	4	6	8	10	11	12	15	16	18	7	2.1
GW4-20-30	II		*	1	2	3	4	5	6	7	8	9	10	10	3.0
6" Discharge															
CW6 24 49	I		*	2	3	5	6	8	9	10	12	14	16	8	2.4
GW0-24-40	II		*	1	2	3	4	5	6	7	8	9	10	12	3.7
CW6 20 60	I		*	1	2	3	4	5	7	10	10	11	12	10	3.0
GW6-30-60	II		*	1	1	2	2	2	2	3	4	5	5	16	4.9
*This application is too small for this model Air Blaster.															

Aiming the Air Blast: For Air Blasters to provide the greatest effect, it is important to aim them properly. Direct the blast at problem areas such as corners and the base of any known or suspected areas of bridging, arching, rat holing, or clinging. However, directing the blast straight out into the storage structure most often has disappointing results. A much more productive blast is one that skims the internal surface of the structure, forcing the problem material from the wall and allowing gravity to pull it down towards the storage vessel outlet. Therefore, where possible, direct the blast so it will parallel the inside wall, shearing material away from the wall to restore material flow. Since this is often difficult, Global Manufacturing developed and patented a Tangential Mount system. With Tangential Mounting the Air Blaster discharge is directed downward at a steep angle and to the side. This achieves the following:

1. The "tangential" angling of the discharge (at least 60° below the perpendicular to the storage structure wall) helps the blast to skim material from the wall.

2. The downward orientation pushes the bulk material toward the storage structure outlet and also prevents loosened material from entering the discharge pipe and possibly contaminating the Air Blaster valve. 3. The sideward angling of the discharge (same direction for all Air Blasters on the structure) helps expand the area of influence around the circumference of the structure and promotes a "cyclone" motion of the material all in one rotary direction, further assisting in the flow of material.

When using tangential mounting, overlap blast patterns to give the most effective coverage. Aim the first Air Blaster towards the outlet of the storage structure. Spiral Blasters around the structure, always keeping in mind the area of influence.



Q

Q



Examples of Air Blaster System

Configurations using

Tangential Mounting

To assist with mounting and aiming of Air Blasters, Global Manufacturing offers **Tangential Mount Discharge Assemblies**. These mount assemblies which can be welded or bolted to the storage structure direct the air blast downward (60° below the perpendicular to the wall) and 20° to the right. The discharge assembly supports the Air Blaster as well (see pg 11 for adequate structure wall thickness) and includes a mount flange for the Air Blaster and all hardware. Shown is a Tangential Mount Discharge Assembly with a 4" discharge. Also available for a 2.5" or 6" discharge. (Either a ring gasket or full-face gasket is supplied with discharge assembly.)



Air Blaster Orientation: In general, it is best to mount the Air Blaster so the discharge pipe is straight and as short as possible. This allows the maximum blast force to be applied to the material in the storage vessel. A downward slant to the discharge pipe helps prevent the stored material from contaminating the Air Blaster. However, due to space limitations, these guidelines cannot always be followed. Sometimes the discharge pipe will have to have a bend or be longer in length, and the Air Blaster may need to be oriented at different angles. If the air source is of poor quality, containing much water, or if condensation is a problem, the Air Blaster pressure vessel will need to be drained occasionally. To assist in draining the tank, three accessory ports are provided; one on the side of the tank, one on the end near the discharge,

and one on the end near the air inlet. When mounting, be sure the Air Blaster is oriented so two of these ports are pointed downward. Once the Air Blaster is mounted, place a drain valve in the lowest of the three ports. One of the other accessory ports is used for the safety relief valve (provided with the Air Blaster). Air Blasters manufactured before May 2001 have only two accessory ports. They do not have the port on the end of the tank opposite the discharge pipe (next to the current air inlet port).



800.551.3569 TOLL FREE USA & CANADA 501.374.7416 TEL 501.376.7147 FAX www.GlobalManufacturing.com



Required Storage Structure Wall Thickness: The storage structure wall must be rigid enough to support the weight of the Air Blaster and withstand the forces that occur during discharge. Reinforce structure walls less than $3/_{16}$ " (5 mm) thick. Please see minimum thickness requirements below. Tank Mount Hardware is available from Global Manufacturing to help support the weight of the Air Blaster and withstand the firing forces.

Air Blaster	Wei	ight	Minimum Wall Thickness		
Model	lb	kg	inches		
GW2.5-8-24	56	25	3/16		
GW4-12-28	94	43	3/16		
GW4-16-34	116	53	3/16		
GW4-20-30	128	58	1⁄4		
GW6-24-48	260	118	1⁄4		
GW6-30-60	554	251	1⁄4		

Air Blaster Plumbing: As described under "Required Accessories" (page 6) there are a number of air control components necessary for full operation. To ensure safe operation and optimum performance of your Air Blaster system, install these air control components as shown in the plumbing diagrams in Appendix D, page 27. The "Using a Quick Exhaust Valve Air Blaster Plumbing Diagram" gives the highest level of performance while allowing the control valve (manual or solenoid) to be located up to 100 feet (30 m) from the Air Blaster. "Not Using a Quick Exhaust Valve Air Blaster Plumbing Diagram" will also give high performance if the control valve (manual or solenoid) is located within 10 feet (3 m) of the Air Blaster.

Visual Inspection: Please note the condition of the shipping container before opening. The shipping container will include the Air Blaster, pressure relief valve and operating instructions. Make sure all parts are located before discarding the container. Inspect the Air Blaster for any damage, such as dents, that might have occurred during shipment. Any Air Blaster accessories (valves, discharge assemblies, timers, etc.) ordered from Global Manufacturing will be packaged separately. Please verify that all items ordered have been received. Contact Global Manufacturing Customer Service or your distributor if there are any missing parts, apparent damage, or other irregularities. Report any damage to the delivery service. Complete any necessary claim forms.



Temporary Plug Removal: Tank openings are fitted with plastic plugs which are removed prior to attaching the air line, discharge pipe, or pressure relief valve. The small port at the end of the tank near the discharge opening has a steel plug. This is a permanent plug that should not be removed unless this port is needed for a drain valve or as an alternate location for the pressure relief valve.

WARNING!

Before working on any storage structure, lock out - tag out any equipment that loads or unloads material from the structure.

If equipment will be installed in an enclosed area, test gas levels or dust content before using a cutting torch or welding equipment. Using a cutting torch or welding in an area with sufficient gas or dust levels can cause an explosion.

Installing Discharge Pipe: The discharge assembly must be able to support the Air Blaster and directs the air blast towards the problem area.

Structure Wall Opening: Instructions for making the opening for the discharge pipe in the storage structure wall are not specific because of the wide variety of structures, wall materials, etc. Generally, the hole in the wall for the discharge pipe will be circular if the pipe is entering perpendicular to the wall or elliptical if using Global Manufacturing's patented Tangential Mounting. The chart in Appendix G, page 32, defines the height and width of the ellipse for each of the three discharge pipe sizes offered. These are for a 60° downward slope (from perpendicular to the wall surface) and a 20° rotation to the right.

800.551.3569 TOLL FREE USA & CANADA 501.374.7416 TEL 501.376.7147 FAX www.GlobalManufacturing.com Global Viber

Important!

Before cutting a hole in the structure wall, be sure there is adequate space to mount the Air Blaster to the discharge assembly.

Discharge Pipe Features: If not using a discharge assembly provided by Global Manufacturing, please use the following guidelines in constructing a discharge pipe:

1. Use schedule 40 steel pipe for most applications.

2. Avoid sharp bends in the discharge pipe. Where bends are necessary, use a long radius elbow for a more effective blast.

3. Keep the length of the pipe as short as possible. The longer the discharge pipe, the more the blast force is diminished. If the pipe must be more than 6 feet (1.8 m) long consider using the next larger size Air Blaster.

4. When determining the pipe length keep in mind the length of pipe needed to give proper clearance for the Air Blaster tank to clear the structure wall, the thickness of the wall, and the amount of pipe that will be extending into the storage area.

5. The pipe should extend into storage area only far enough to clear the inner wall.

6. Use a standard slip-on pipe flange to mount the Air Blaster to the discharge pipe. Select the size (2.5", 4.0", or 6.0") to match the pipe size and the mounting flange on the Air Blaster.

Installing the Global Tangential Mount Discharge Assembly:

1. Determine the location of the Air Blaster discharge pipe. Be aware of structural obstacles which may interfere with mounting the Air Blaster to the mount flange on the end of the discharge pipe.

2. Using the Coordinates and Dimensions of Elliptical Openings in Appendix G, make a template of cardboard or other durable material. Enlarge the elliptical shape of the pattern by $\frac{1}{2}$ " (13mm) for ease of fitting during installation. The pattern may also be used to locate bolt holes if the mount plate is to be bolted to the structure wall.



3. Use the pattern to mark the opening on the structure wall. When working from the outside of the structure, the long diameter of the elliptical shape should run from upper left to lower right (unless you have ordered a special configuration).

4. Cut the hole in the structure wall.

5. Fit the discharge pipe into the wall so the mount plate is flush with the outer wall surface. Evaluate the amount of pipe extending into the storage chamber. Cut the pipe using a square cut (perpendicular to the length of the pipe) so the lower edge is flush with the inside of the structure wall. The upper edge will protrude into the flow area slightly.

6. Be sure the discharge assembly is in place with the mount plate flush with the outer wall surface. Seal weld the mount plate to the wall.

800.551.3569 TOLL FREE USA & CANADA 501.374.7416 TEL 501.376.7147 FAX www.GlobalManufacturing.com



NOTE If the storage structure wall is too curved and leaves an excessive gap for welding, trim the mount plate with a torch to the required size to reduce the gap as shown below. Do not trim the mount plate closer than 2" (50 mm) from the discharge pipe. The remaining flange must overlap the mounting surface by at least ½" (12 mm). After trimming the mount plate, reposition the discharge assembly in the structure wall and seal weld the mount plate to the outer wall surface.



NOTE

If the discharge assembly will be bolted to the structure wall, use

at least four (4) 5/8" (16mm) bolts to secure the mount plate. Drill holes in mount plate at least 11/2" in from each corner. Anchor bolts must extend at least 3" into the concrete wall. Otherwise the bolts should extend through the wall and be secured with lock washers and nuts. Use gasket material between the mount plate and structure wall or apply sealant to the mount plate-wall joint to prevent air or material leakage.

Mounting Air Blaster to the Discharge Pipe

The Air Blaster coupling flange is connected to a discharge pipe equipped with a mount flange. Be sure to rotate the Air Blaster to place the small ports facing downward (in case they will be needed to drain the Air Blaster tank at a future time).

A WARNING!

The discharge pipe must be securely mounted to the storage structure wall. If any doubt about the rigidity of the mount exists, Global Manufacturing strongly recommends using additional mount hardware to secure the Air Blaster. Contact Global Manufacturing or your distributor.

1. Secure the Air Blaster coupling flange to the mounting flange on the discharge assembly using a gasket (either full-face or ring gasket) and the Grade 5 bolts, nuts, and washers provided. Use bolts no smaller than $\frac{1}{8}$ " (3 mm) less than the coupling bolt hole diameter. The bolts are tightened in three stages in a crisscross pattern to ensure even tightening.

2. Be sure to install a safety cable to keep the Air Blaster from falling should it break loose from its mount. Use the ring on the end of the tank for this purpose. Securely attach the other end of the safety cable to a structural member.





800.551.3569 TOLL FREE USA & CANADA 501.374.7416 TEL 501.376.7147 FAX www.GlobalManufacturing.com



WARNING!

If the Air Blaster is mounted more than 6" (152 mm) above the ground, secure the Air Blaster to a structural member with a safety cable to prevent the Air Blaster from falling and causing serious injury if it came loose from its mount.

If a safety cable kit has been purchased from Global Manufacturing, attach one end of the cable to the steel ring with the provided clamp. The steel ring can be welded to or looped around a structural support. Using the other clamp, attach the other end of the cable to the safety tab on the end of the Air Blaster tank. Adjust the length of the cable to provide some slack. It should be short enough, however, to stop the Air Blaster from falling and hitting a person.



3. If a drain valve (not supplied) is to be used, install it in the lowest of the three small accessory ports (The tank should be mounted so two of these ports point down). Install the pressure relief valve (safety valve) in the side accessory port, or if that one has been used for a drain valve, in the unused port on either end of the tank (will have to remove the steel plug).



Important!

Be sure to apply $\ensuremath{\mathsf{Teflon}}^\ensuremath{^{\ensuremath{\mathbb{R}}}}$ tape to all threaded connections.

General Piping Instructions for Air Blaster System Air Control Components: To ensure safe operation and optimum performance of your Air Blaster system, install necessary air control components as shown in the plumbing diagrams in Appendix D, page 27.

1. The **"Using a Quick Exhaust Valve Plumbing Diagram"** makes use of a quick exhaust valve and gives the highest level of performance while allowing the control valve (manual or solenoid) to be located up to **100* feet** (30 m) from the Air Blaster. **"Not Using a Quick Exhaust Valve Plumbing Diagram"** will also give high performance if the control valve (manual or solenoid) is located within 10 feet (3 m) of the Air Blaster. The distance between the other components is not important except when the Quick Exhaust Valve is connected directly to the Air Blaster inlet port on the pressure vessel. Only the sequence of the components along the air supply line is important.

NOTE *When the 3-Way Control Valve (Solenoid or Manual Valve) is a significant distance from the Air Blaster, there will be a time delay between the closing of the Control Valve and the actual discharging of the Air Blaster. This may need to be addressed with automatic systems.

2. Do not connect more than four Air Blasters to a single Filter-Regulator-Gauge / Shut-off Valve pair.

3. The air supply lines required for plumbing Air Blasters and control components must be rated for a minimum of 150 psi (10.3 bar). Use ³/₄" air lines or greater. If a timer is used to control Air Blaster firing sequence and time delay between blasts, wire each solenoid valve to the appropriate timer terminals. Wiring must adhere to all appropriate electrical standards.

800.551.3569 TOLL FREE USA & CANADA 501.374.7416 TEL 501.376.7147 FAX www.GlobalManufacturing.com







Air Blaster Control Component Installation:

Install each control component using $\mbox{Teflon}^{\mbox{$\it ®$}}$ tape on all threaded connections.

WARNING!

Be sure all connections are air tight. Any leak along the Air Blaster air supply line may cause the Air Blaster to discharge unexpectedly causing injury.

Shut-off Ball Valve Installation: The 2-way shut-off ball valve is used to isolate the Air Blaster system from the plant air supply. A ³/₄" valve is recommended. Locate it between the plant air supply and all other components in the Air Blaster system. Each shut-off valve should control no more than four Air Blasters. Be sure to clearly label the shut-off valve and place it where it can be quickly and easily reached in an emergency or for routine maintenance.



2. **Filter-Regulator-Gauge:** Install the filterregulator-gauge (FRG) in the air supply line between the shut-off ball valve and the check valve. The FRG is designed to prevent damage to the Air Blaster

and control components by filtering water and particulate contaminants from the air supply. A ³⁄₄" FRG is recommended. Place the FRG where the filter reservoir can be drained daily (unless an auto-drain model is used). The FRG has an arrow cast in the housing, which indicates the required direction of air flow. It will not function if it is installed



in the reverse direction. After installation set the air pressure to the Air Blaster between 80 and 100 psi (5.5 and 6.9 bar) for most applications (If using a solenoid value in the system, the pressure should not be below 40 psi).



3. **Check Valve Installation:** The check valve prevents accidental firing of the Air Blaster if an unexpected decrease in line air pressure occurs. The check valve maintains pressure to the Air Blaster by preventing the backward flow of air. Install the check valve in the air supply line between the FRG and the 3-way control valve (manual or solenoid). A ³/₄" valve is recommended. Be sure to install the valve with the cast-in arrow pointing in the direction of the air flow. If used in a horizontal line, be sure the hex head plug is on top, so the check valve will close properly. In a vertical line, the air flow must be upward in the line.

🛕 Warning!

Do not install in a vertical line where the air flow is downward, because the check valve will not close properly.

Do not install with the hex head plug on the bottom or pointing downward, because the check valve will not close properly.

Check Valve in Proper Orientation



Check Valve in Improper Orientation



4. **3-Way Normally Open Valve Installation:**

This valve controls the operation of the Air Blaster. Use either a manual valve for manual control or a solenoid valve for remote or automatic control. The solenoid valve is wired to either a remote manually triggered momentary switch or a micro-controller based sequencing timer such as Global's BLASTER MASTER timer. Be sure the controller output is compatible with the electrical requirements of the solenoid valve. Follow all applicable local wiring codes.

Control Valve Illustrations:

Manual 3-Way Valve

Manual 3-Way Valve

Handle in "Fill" Position



3/4" 3-Way Open Solenoid Valve



The control valve is installed in the air supply line between the check valve and the Air Blaster. Location depends on whether a quick exhaust valve is being used or not.

800.551.3569 TOLL FREE USA & CANADA 501.374.7416 TEL 501.376.7147 FAX www.GlobalManufacturing.com



Quick Exhaust Valve Not Used: Install the 3-Way Control Valve **within 10 feet** (3 m) of the Air Blaster. Refer to the table below to determine the size of the valve and the appropriate fittings for each Air Blaster model. If a solenoid is used, be sure it is set in the normally open position ('3-NO' is indicated on the small white tab visible from the top). Using an appropriate bushing connect the ³/₄" air supply line to the valve air inlet port. The valve outlet is connected to the Air Blaster inlet port using the appropriate close pipe nipple or flexible air line.

Connections Without Quick Exhaust Valve									
Air Blaster Model	3-Way Valve Size	Solenoid Inlet Port Label	Inlet Bushing Size	Solenoid Outlet Port Label	Pipe Nipple Size for AB Tank Mounting	Air Line Size for Remote Mount > 10'			
GW2.5-8-24	3⁄4"	1	N/A	2	³ ⁄4" x close	3⁄4 "			
GW4.0-12-28	3⁄4"	1	N/A	2	3⁄4" x close	3⁄4 "			
GW4.0-16-34	3⁄4"	1	N/A	2	3⁄4" x close	3⁄4 "			
GW4.0-20-30	3⁄4"	1	N/A	2	3⁄4" x close	3⁄4"			
GW6.0-24-48	1"	IN	1" x ¾"	2 CYL	1" x close	1"			
GW6.0-30-60	1"	IN	1" x ¾"	2 CYL	1" x close	1"			

Contamination Protection: Connect a street elbow to the solenoid or 3-way firing valve's exhaust port (or the QEV for GW2.5-8-24 but not necessary for Global's manufactured 1" QEV). Position the elbow to point downward and add a 3" long nipple for exhaust extension. Refer to the table below for the appropriate size fittings to be used. The elbow with extension will keep contaminants from entering the valve through the exhaust port. **Using a muffler to protect the exhaust port is not recommended, because it will reduce Air Blaster performance by significantly impeding the exhaust air flow.**

Solenoid Valve Size	Exhaust Port Label	Street Elbow Size	Nipple Size
3⁄4"	3	3⁄4"	³⁄4" x 3"
	2	pn 293412	pn 294612
1"	EVH	11⁄2"	1½" x 3"
		pn 293424	pn 294624

Important!

The solenoid valve may not operate if the inlet pressure is less than 40 psi (2.75 bar).



Quick Exhaust Valve Installation for the GW Series: Install a $\frac{3}{4}$ " 3-way control valve **within 100 feet** (30 m) of the Air Blaster (all models). If a solenoid is used, be sure it is set in the normally open position ('3-NO' is indicated on the small white tab visible from the top). Connect the $\frac{3}{4}$ " air supply line to the valve air inlet port (Solenoid port labeled '1'). The $\frac{3}{4}$ " line connecting the Solenoid to the Air Blaster quick exhaust valve is connected to the valve outlet (Solenoid port labeled '2').

The quick exhaust valve (QEV) allows rapid depressurization of the Air Blaster internal valve assembly, which causes the Air Blaster to discharge. Using the recommended QEV will ensure optimum performance of your Global Air Blaster even when the 3-way control valve is placed more than 10 feet (3 m) from the Air Blaster. **If a smaller QEV is used, it will not have sufficient internal air flow capacity to depressurize the Air Blaster valve quickly enough. The Air Blaster will discharge, but the force of the blast will be greatly reduced.** Install the QEV to the Air Blaster inlet port using the appropriate size close pipe nipple (and bushing if necessary). The ³/₄" air supply line from the 3-way normally open valve is connected at the QEV inlet port.

Installing a Quick Exhaust Valve - Connection Details										
Air Blaster Model	QEV Size	QEV Inlet Port Label	Inlet Size	QEV Outlet Port Label	Pipe Nipple Size for AB Tank Mounting					
GW2.5-8-24	3⁄4"	IN	3⁄4"	CYL	³ ⁄ ₄ " x close (pn 294602)					
GW4.0-12-28	1"	IN	3⁄4"	AB	1" x close (pn 294614)					
GW4.0-16-34	1"	IN	3⁄4"	AB	1" x close (pn 294614)					
GW4.0-20-30	1"	IN	3⁄4"	AB	1" x close (pn 294614)					
GW6.0-24-48	1"	IN	3⁄4"	AB	1" x close (pn 294614)					
GW6.0-30-60	1"	IN	3⁄4"	AB	1" x close (pn 294614)					

Important! Do NOT loosen or remove the 2" plug from the tank when installing QEV.

GW2.5-8-24: This unit uses the Deltrol quick exhaust valve (QEV). All inlets are ³/₄" NPT on the QEV and Air Blaster inlet. Screw a ³/₄" NPT nipple into the Air Blaster inlet, screw "CYL" opening to the nipple, and attach air line from actuator valve to "IN" port. Use pipe thread sealant on all pipe threads. For **Contamination Protection** connect a ³/₄" street elbow to the ³/₄" QEV exhaust port (labeled 'EXH'). Position the elbow to point downward and add a ³/₄" x 3" long nipple for exhaust extension. The elbow with extension will keep contaminants from entering the valve through the exhaust port. It is not recommended to use a muffler to protect the exhaust port - it will reduce Air Blaster performance by significantly impeding the exhaust air flow.



All GW4 Models: These units come with a 1 X ³/₄" NPT bushing installed into the tank air inlet. Remove the air inlet line and this bushing from the tank inlet. Do NOT loosen or remove 2" plug from tank. Replace bushing with 1" NPT nipple. Install "G" Series QEV onto this nipple. Reinstall air line from actuator valve to ³/₄" NPT inlet on QEV cap. Use pipe thread sealant on all pipe threads. The 1" Global "G-Series" QEV does not require **Contamination Protection**. The exhaust port protection is designed into the valve.

All GW6 Models: Basically follow procedure for the GW4 models. The only difference is there is no 1 X ³/₄" NPT bushing to be removed. Use pipe thread sealant on all pipe threads. The 1" Global "G-Series" QEV does not require **Contamination Protection**. The exhaust port protection is designed into the valve.

1" G-Series Quick Exhaust Valve





IV. Air Blaster Start - Up Procedures

1. Make sure all connections for Air Blasters, discharge assemblies, and air and electrical components are secure.

2. Check all 3-Way Control Valves to ensure they are in the open position.

3. Set Filter-Regulator-Gauge (FRG) to minimum pressure position.

4. Open the Shut-off Ball Valve to allow plant air to enter the system.

5. Set the FRG to the pressure desired for charging the Air Blasters: **Minimum pressure = 40 psi (2.7 bar).** Solenoid valves might not operate consistently at lower pressures. **Maximum pressure = 125 psi (8.6 bar).** The Air Blaster tank is rated for 125 psi. Its safety relief valve will release and depressurize the tank if the pressure exceeds 125 psi. Pressure between 80 and 100 psi will give excellent performance for most applications.

6. Check all airline pipe connections for leaks. Mark all leaks found and de-pressurize the system by closing the 2-Way Shut-off Ball Valve, and fire Air Blaster or use pressure relief valve to depressurize system.

7. Repair any leaks found in Step 6 and return to Step 3. If no leaks were found, continue with Step 8.

8. Test each Air Blaster separately. For manual control valves, simply move the lever to the closed position to fire the Air Blaster. Return the lever to the open position to refill the Air Blaster. If solenoid control valves are used, activate the solenoid by pressing the remote switch or by pressing the appropriate timer switch while the timer is in manual mode. Refer to the Troubleshooting Guide, in Appendix A, if the Air Blaster does not fire or has inadequate force.

9. If the Air Blaster System is to be controlled by a micro-controller based sequencing timer, such as the Global Blaster Master Timer, refer to the timer instruction manual to configure the timer for Air Blaster firing sequence, time between blasts, and time between cycles. Test the timer configuration and adjust as necessary to obtain the desired results.

10. After satisfactory completion of the above Steps, your Global Manufacturing Air Blaster system is ready for use.

Important!

To keep contaminants from entering the valve, Air Blasters must be pressurized prior to operating any material flow system.

V. Maintenance

Preventive maintenance is important to ensure effective and safe performance of the Air Blaster system.

Lubrication: No lubrication required.

Air Control Accessories: Check periodically to make sure all valves are clean and functional. The reservoir on the Filter-Regulator-Gauge should be drained daily. Clean unit and filter with warm water and mild soap as needed. Blow with compressed air to dry. Use a 40 micron filter when the filter element needs replacing.

Air Blaster Mounting: All mounts must remain rigid. Check periodically and retighten as necessary. Replace any damaged or rusted parts.

Air Blaster Internal Valve: The Air Blaster valve is designed to provide many years of maintenance free operation. Should the Air Blaster malfunction or performance appear to decrease, inspect the internal valve for wear or contamination. If the Air Blaster is used in a harsh environment, inspect Air Blasters in the system periodically - semi-annually or annually - during routine plant maintenance periods. This rotating inspection schedule should indicate if the Air Blasters are showing any signs of wear or contamination that will need attention. Follow the instructions in section VI Disassembly and Assembly of the Air Blaster.

Spare Parts Recommendations: See System Spare Parts Recommendations in Appendix B. If the Air Blaster is not used in a harsh environment, an inventory of spare parts may not be needed.

Global Manufacturing, Inc $^{ m extsf{ R}}$	800.551.3569 TOLL FREE USA & CANADA	Glob
1801 East 22nd Street	501.374.7416 TEL 501.376.7147 FAX	
Little Rock, AR 72206 USA	www.GlobalManufacturing.com	

VI. Disassembly and Assembly Dismounting the Air Blaster:

Tools Required: Two (2) each socket or box wrench, 500 lb (230 kg) capacity hoist.

WARNING!

The Air Blaster is fired by a sudden pressure drop in the air inlet line, therefore, all pressure within the tank must be relieved before the tank can be dismounted. Failure to relieve air pressure may result in unexpected Air Blaster discharge, causing serious injury or death to nearby persons.

1. Turn off the air supply to the Air Blaster using the 2-way shut off ball valve.

2. Fire the Air Blaster to relieve all the pressure within the tank. If it is not possible to fire the Air Blaster, pull the ring on the pressure relief valve mounted on the Air Blaster tank.



3. Remove the pressure relief valve from the Air Blaster.

4. Disconnect the air line from the Air Blaster air inlet port. If a quick exhaust valve or solenoid valve has been mounted at the inlet port, remove the air line from that device.

5. Loosen the mounting bolts connecting the Air Blaster coupling to the discharge pipe. Be sure <u>not</u> to loosen the bolts connecting the coupling to the Air Blaster tank.



6. Using the hoist, support the Air Blaster by the ring on the end of the tank. Remove the safety cable.

7. Remove the mounting bolts previously loosened and lift the Air Blaster clear of the discharge pipe. If the gasket between the tank flange and coupling flange is damaged, discard it and use a new gasket of the same type when remounting the Air Blaster. If the gasket is in good condition, it can be reused when remounting the Air Blaster.

8. Lower the Air Blaster to the ground and transport it to an appropriate working area.

Removing the Internal Valve:

Tools Required: Two (2) each socket or box end wrench, 24" pipe wrench, and large adjustable wrench. Refer to the Air Blaster parts list in Appendix F.

NOTE

The internal fill line does not have to be removed to access

the internal valve.

Important!

Do **not** remove the fill line or bushing from tank.

1. Remove the bolts that fasten the coupling to the tank flange. Remove the coupling and the gasket from the Air Blaster. If the gasket is damaged, discard it and use a new gasket of the same type when assembling the Air Blaster. If the gasket is in good condition, it can be reused.





Valve

Body

Pisto

Seat

2. Push the piston up into the valve. Insert fingers into the valve body and carefully pull out the valve body from the tank and off of the fill line.



3. Check the end of the fill line for damage or burrs. Check the fill line for cracks or other damage.



4. Inspect the inside of the Air Blaster tank for corrosion and contamination. Clean the inside of the tank with compressed air prior to reassembly.

Valve Disassembly:



Tools Required: Arbor press, large retaining ring pliers, and a small flat blade screw driver. (A soft wooden block and hammer may be used in place of the Arbor press).

1. Use the large retaining ring pliers to remove the retaining ring in the valve body, at the base of the valve cap.

WARNING!

The retaining ring is under high tension. Use care to ensure the ring does not fly off the pliers or out of the valve body and injure nearby persons.



2. Inspect the retaining ring and retaining ring groove for wear or damage. Replace retaining ring or valve body if damage is evident.

3. Using the arbor press, carefully remove the piston, and valve cap from the valve body. Light pressure on the face of the piston may be necessary.

4. After the piston and valve cap are removed, press the valve seat from the valve body.

5. Use the flat blade screw driver to carefully pry the o-rings from the valve seat, piston and valve cap.

Valve Inspection:

1. Clean all valve parts thoroughly in a non-solvent based cleaner.

2. Inspect the valve body bore for deep scratches, pits, grooves, or corrosion. The valve body bore must be in good condition to function properly.

3. Inspect the sealing face of the valve seat for smoothness. The valve seat must be smooth to properly seat the piston.

4. Check the piston face, sealing bevel, and o-ring for heat damage, chemical erosion, or signs of wear. The piston must be in good condition with smooth sealing and wear surfaces. Minor pitting in the nose of the piston is acceptable if the pits are less than $^{1}/_{16}$ " (2 mm) deep and the sealing bevel is not pitted. Any distortion of the piston which hampers smooth sliding or exhibits excessive clearance in the valve body is unacceptable.

5. It is recommended that, once removed, all o-rings on the piston, valve seat, and valve cap be replaced with type meeting manufacturer's specifications.

Global Manufacturing, Inc ®
1801 East 22nd Street
Little Rock, AR 72206 USA



Assembling the Valve:

1. Replace the o-rings on the valve seat, valve cap, and piston. The piston uses a "floating" type o-ring fit, therefore the piston o-ring will not fit tightly in its groove. **Sparingly** coat all o-rings (**except the o-ring on the cap that serves as the check valve**) with silicone lubricant/grease. Be careful not to damage the o-rings.



2. Assembly of the Air Blaster valve proceeds in the reverse order of disassembly except **all parts are individually pressed** into the valve body. **Do not press all parts in at the same time**. Using the press, position the valve seat (bevel side up) completely down into the valve body. The beveled side of the seat should match the beveled face of the piston. Take care that the o-ring is not cut as it passes over the window openings in the valve body.

3. Align the o-ring in the groove on the side of the piston.

4. Making sure the piston remains straight, push the piston (bevel face down) and o-ring into the valve body until the o-ring approaches the valve cap seat (shoulder machined inside valve body at top of piston bore).

5. Due to the floating o-ring fit, the o-ring may bind as it tries to pass over the valve cap seat, preventing the piston from sliding smoothly into the bore. While using only hand pressure on the piston, use a thin piece of metal or screw driver to work the o-ring into the piston groove, allowing the piston to slide completely into the bore.











6. Press the valve cap into the valve body until it reaches the valve cap seat. The retaining ring groove will be visible above the cap.



7. Install the retaining ring using the retaining ring pliers. The retaining ring will have a sharp edge and a rounded edge. Check the sharp edge of the retaining ring for burrs or rounded areas. Install the retaining ring with the sharp edge away from the valve cap. Check that the retaining ring is properly seated in the valve body groove.

8. Check the piston to make sure it slides easily within the valve body and does not cock enough to allow the damper plug to contact cap

9. Check the o-ring check valve on the valve cap to see that it is properly seated in its groove.

Assembling the Air Blaster:

1. If the internal fill line was removed as an assembly with its 2" NPT bushing, it must be reinstalled as an assembly into the tank. The **bushing must be** sealed with Teflon[®] tape or equivalent. If the fill line must be replaced, the replacement must be installed tightly into the 2" NPT bushing (with thread sealant) and reinstalled into the tank as an assembly. Use a box end wrench to install the fill line into the bushing, as an adjustable wrench will collapse the copper fitting before it is tight enough. The bushing may be held securely in a bench vise during fill line installation. Install fill line/bushing as an assembly into the tank. The bushing must be tight! The valve end of the fill line must be smooth, burr free, and lightly beveled as to allow it to easily enter into the valve cap. See illustration on next page.





2. Examine the end of the internal fill line from the tank discharge opening. The fill line must be centered within the tank opening. If it is not centered, use a rod slipped into the end of the fill line to bend the tube so it appears centered.



3. Apply a tiny amount of silicone grease to the end of the fill line prior to installing the valve assembly.

4. Install the valve assembly in the tank opening, taking care to slide the inlet port on the valve cap over the end of the fill line. When contact is made between the fill line and the o-ring seal in the cap inlet port, twist and slightly rock the valve until the valve slips fully into the recess in the tank flange.

5. Inspect and install the flange coupling. Be sure to use a new gasket, if necessary, between the Air Blaster tank flange and the coupling flange. The gasket should meet manufacturer's specifications. No adhesive is required.



Testing the Air Blaster:

After assembly and before mounting the Air Blaster on the discharge pipe, test the Air Blaster.

WARNING!

Use eye and ear protection when testing the Air Blaster.

Warn all personnel in the testing area to stay clear of the discharge outlet.

Be sure no objects within 25 feet are in the path of the air blast.

1. Clamp or wedge the Air Blaster in place on the floor so that it cannot move from the recoil when fired.

2. Install the pressure relief valve in the Air Blaster tank. Be sure to use pipe thread sealant.

3. Attach a quick disconnect on the Air Blaster inlet port.

4. Attach an air hose to the quick disconnect and fill the tank to about 40 psi (2.8 bar).

5. Remove the air hose to discharge the Air Blaster.

Important!

Air Blaster Mounting: All mounts must remain rigid. Check periodically and retighten as necessary. Any damaged or rusted parts should be repaired or replaced.

Air Blaster Internal Valve: The Air Blaster valve is designed to provide many years of maintenance free operation. Should the Air Blaster malfunction or performance appears to decrease, the internal valve should be inspected for wear or contamination. If the Air Blaster is used in a harsh environment several Air Blasters in the system should be inspected periodically semi-annually or annually - during routine plant maintenance periods. This rotating inspection schedule should indicate if the Air Blasters are showing any signs of wear or contamination that will need attention. Follow the instructions in section VI - Disassembly and Assembly of the Air Blaster.

Spare Parts Recommendations in Appendix B. If the Air Blaster is not used in a harsh environment, an inventory of spare parts may not be needed.



Appendix A - Troubleshooting

Prior to shipment, all Global Air Blasters are tested for pressure and function according to corresponding pressure vessel regulations and quality manufacturing specifications. Despite the simple and sturdy construction, malfunctions can occur due to the kind of application, installation, and/or operation. The following list should help identify the causes of some problems that occur and gives possible solutions to eliminate those problems.

Control Valve = 3-Way Normally Open Manual or Solenoid Valve.

Operating Valve = Quick Exhaust Valve.

PROBLEM: Air Blaster discharges with weak or no blast								
Probable Cause	Solution							
Air leakage in control valve or operating valve.	Check control valve and operating valve for wear, damage, contamination. Check for system leaks. Replace if leaking.							
Control or operating valve is malfunctioning.	Check air filtering system. Clean or repair valves as needed.							
Control valve is too far from the Air Blaster, or the size of the valve is too small.	Control valve must be within 10 feet of the Air Blaster. If distance is greater, install a Quick Exhaust Valve at the Air Blaster. Be sure valves are the recommended size.							
Piston lodged in valve due to contamination.	Disassemble and clean valve assembly. Check filter element. If sliding surfaces are damaged, replace valve assembly.							
Low air pressure.	Check pressure at Air Blaster and increase regulator setting. Use a larger diameter fill line. Minimum line size between control and operating valves is 3/4".							
Air Blaster not completely filled before it is discharged.	With manual firing give the Air Blaster more time to fill. Increase the between blast time on the timer. Use a larger diameter fill line.							
Sharp bends in the discharge pipe reduce force output.	Use long radius elbows.							
Discharge pipe is blocked with material.	Clean pipe and reposition it to prevent material from entering.							
Discharge pipe is too long.	Air Blaster should be as close as possible to discharge opening.							
Piston is not sealing.	Clean or replace piston and o-ring. Check valve seat for dents, nicks, etc. The piston and valve seat must seal.							
Pressure vessel (tank) is punctured or cracked.	Replace pressure vessel.							
Air Blaster is firing into an area void of material.	Air Blaster discharge should be above the blockage of material to blast through the blockage.							



Appendix B - Air Blaster Suggested Spare Parts

Air Blaster Suggested Spare Parts	QTY	GW2.5-8-24	GW4-12-28 GW4-16-34 GW4-20-30	GW6-24-48	GW6-30-60
Part Descriptions			Part N	umbers	
Pressure Relief Valve	5%	290408	290408	290408	290408
Valve Assembly - Complete	5%	305725	305740	305760	305760
Valve Seat	5%	304625	304640	304660	304660
Piston	5%	275725	275740	275760	275760
O-rings - Complete set of 7 except GW2.5 has only 5*	10%	385002	385004	385006	385006
Seat - Buna (1)*		385228	385240	385431	385431
Piston - Buna (1)*		385331	385343	385436	385436
Piston Nose - Viton (1)		N/A	386237	386254	386254
Piston Damper Plug (1)		N/A	386208 Viton	385212 Buna	385212 Buna
Cap - Main - Buna (1)*		385331	385343	385436	385436
Cap - Exhaust - Buna (1)*		385324	385331	385343	385343
Cap - Fill Line - Buna (1)*		385112	385118	385122	385122
Retaining Ring	10%	347250	347400	347625	347625
Gaskets	10%	296125	296140	296160	296160
Quick Exhaust Valve Need ¾" close nipple (pn 294602) to install QEV	5%	290512	308010	308010	308010
3-Way N/O Solenoid 110V	5%	456112	456112	456112	456112
3-Way N/O Solenoid 24V required if using Global's TMB-II-06 Timer	5%	458214	458214	458214	458214

The life expectancy of Global GW Series Air Blasters is indefinite when operated using dry, clean air at ambient temperatures below 130°F. Actual life will be affected by the quality of air, environmental conditions, and mounting position. All Global GW Series Air Blasters are covered by a Lifetime Warranty. If an Air Blaster fails due to defect in materials or workmanship, Global will repair or replace the Air Blaster without charge to the customer.



Appendix C - Air Blaster Dimensions - GW Series



Air Blacter		Α	В	С	D	E	F	G	н		
Model	Weight	Discharge Size	Tank Diameter	Tank Length	Coupling Length	Flange Diameter	Total Length	Total Width	Inlet Port		
	lb	in	in	in	in	in	in	in	in		
	kg	mm	mm	mm	mm	mm	mm	mm	NPT		
2.5" Discharge	2.5" Discharge										
	56	2.5	8	24	4.5	7	31.2	10.7	3/4		
GW2.3-6-24	25	64	203	610	114	178	792	272	94		
4" Discharge											
CWA 12 29	94	4.0	12	28	4.6	9	35.3	14.7	3/4		
GW4-12-20	43	102	305	711	117	229	897	373	9/4		
CW4 16 24	116	4.0	16	34	4.6	9	41.1	18.7			
GW4-10-34	53	102	406	864	117	229	1044	475			
CW4 20 20	128	4.0	20	30	4.6	9	37.3	22.7	3⁄4		
GW4-20-30	58	102	508	762	117	229	947	577			
6" Discharge											
CW6 24 49	260	6.0	24	48	6.0	11	56.7	26.7	1		
GW6-24-48	118	152	610	1219	152	279	1440	678	L		
CWC 20 C0	554	6.0	30	60	6.0	11	68.7	32.7	1		
GW0-30-00	251	152	762	1524	152	279	1745	831			



Appendix D - Air Blaster Plumbing Diagrams





Using a Quick Exhaust Valve

- $1^* = \frac{3}{4}$ " Shut-Off Ball Valve
- 2* = 3/4" Filter/Regulator/Gauge
- 3* = ³/₄" Check Valve
- 4 = ³/₄" 3-Way Normally Open Control Valve
 - = 1" Global's Quick Exhaust Valve (QEV)
 or ³/₄" QEV for 2.5" AB
 - *or* use Global's GWE Air Blaster Model which comes with installed QEV
- AB = Air Blaster

*Can use 1/2" but 3/4" fills faster

34" Airline rated for 150 PSI (10.3 Bar)

1/2" Airline rated for 150 PSI (10.3 Bar)

Notes:

5

Airlines and fittings have NPT threads.

Use 1 Filter/Regulator for every 4 AB's.

This configuration provides optimum Blaster performance and allows the control valve to be located up to 100 feet from the Air Blaster.

No Quick Exhaust Valve Used

- 1* = ³/₄" Shut-Off Ball Valve
- 2* = 3/4" Filter/Regulator/Gauge
- 3* = ³/₄" Check Valve
- 4 = ³/₄" 3-Way Normally Open Control Valve and use a

1" 3-Way Normally Open Control Valve for all 6" Air Blasters

AB = Air Blaster

*Can use 1/2" but 3/4" fills faster

34" Airline rated for 150 PSI (10.3 Bar)

1/2" Airline rated for 150 PSI (10.3 Bar)

Notes:

Airlines and fittings have NPT threads.

Use 1 Filter/Regulator for every 4 AB's.

This configuration provides optimum Blaster performance when the Control Valve (4) is located within 10 feet of the Blaster. Using a smaller control valve or placing it further than 10 feet from the Blaster will significantly decrease AB performance. If control valve must be located further than 10 feet from AB, install appropriate QEV.

Air Bister ModelAir Pressurepsi708090100Bar4.85.56.26.9Lar4.04.55.05.5SolschargeFree Air Volume113127141155GW2.5-8-24Fill Timesec-0.00.90.90.9Tank Volume is 0.7 if (19)Force1bf244275288330ForceIbfr2.442.752.863.003.74GW4-12-28Ffree Air Volume1br2.773113403.74GW4-12-38Force1bf867102112.0013.00Tank Volume is 1.7 ft.3 (49)Force1bf877102112.001300Tank Volume is 3.5 ft.3 (49)Force1bf877102112.001300ForceIbfr3009310.009999Free Air Volume1bf3.002.33350350ForceIbfr3003.316.026.58GW4-16-34Fill Timesec7.335.45.31Tank Volume is 3.5 ft.3 (91)Force1b/ft.35.316.026.58Ar DischargeFree Air Volumeft.22.35350350GW4-16-34Free Air Volumeft.23.53.516.02ForceIb/ft.35.05.316.026.58Ar Dischargeft.1Ib/ft.33.003.00100	Appendix E	:	Air Blaste	er Perforı	mance Data	for GW M	odels
Model Pressure bar 4.8 5.5 6.2 6.9 2.5 Discharge $Fr@ AIr Volume R^2 4.0 4.5 5.0 5.5 GW2.5-8-24 Fill Time sec -(10) $	Air Blaster	Air	psi	70	80	90	100
Prec Air Volume \hbar^2 4.0 4.5 5.0 5.5 GW2.5-8-24 Find Time sec <113	Model	Pressure	bar	4.8	5.5	6.2	6.9
2.5 Discharge Free Air Volume liters 113 127 141 155 GW2.5-8-24 Fill Time sec <10 <10 <10 <10 Tank Volume is 0.7 ft ³ (191) Force libf 244 275 288 330 4" Discharge Efficiency libf 244 275 288 330 4" Discharge Free Air Volume ft ² 9.8 11.0 12.0 13.2 6W4-12-28 Free Air Volume ft ² 9.8 11.0 12.0 13.2 5 hot Time sec 0.8 0.8 0.8 0.8 0.8 1.7 ft ³ (491) Force libf 877 102.1 1200 1300 4" Discharge Free Air Volume ftill Time sec 23.5 35 35 GW4-16-34 Free Air Volume ftill Time sec 13 1.5 1.5 3.5 ft ³ (91) Free Air Volume ftill 976 1185 132			ft ³	4.0	4.5	5.0	5.5
GW2.5-8-24 Tank Volume is 0.7 ft ³ (191) Fill Time sec sec (-10) (-1	2.5 Discharge	Free Air Volume	liters	113	127	141	155
GW 2-5-8-24 Shot Time sec .08 .09 .09 .09 Tank Volume is 0.7 ft 3 (19 i) Force Ibf 244 275 288 330 4" Discharge GW 4-12-28 Efficiency Ib/t ³ 61 61 58 60 3.7 ft 3 (9 i) Free Air Volume Rt ³ 9.8 11.0 12.0 13.2 GW 4-12-28 Free Air Volume Rt ³ 9.8 0.08 0.08 0.08 0.08 Tank Volume is 1.7 ft 3 (49 i) Force Ib/f 877 1021 1200 1300 4" Discharge GW 4-16-34 Free Air Volume Ib/f ³ 90 93 100 99 4" Discharge GW 4-16-34 Free Air Volume Ib/f ³ 20.0 22.4 24.8 27.0 5 shot Time sec .13 .15 1.32 .15 .15 GW 4-16-34 Free Air Volume Iters S66 634 702 765 5 shot Time sec .13 .15		Fill Time	sec	<10	<10	<10	<10
Tank Volume is 0.7 (191)Porcelbf2442752883304" Discharge GW4-12-28 Efficiencylb/k ³ 616158604" Discharge GW4-12-28 Free Air Volumelters2773113403745hot Timesec151515151.7 (491)Forcelb/f877102112.0013.001.7 (491)Forcelb/f877102112.0013004" Discharge GW4-16-34 Free Air Volumelb/f39093100994" Discharge GW4-16-34 Free Air Volumelters5666347027655hot Timesec25353535355hot Timesec253535355hot Timesec253535355hot Timesec253554545hot Timesec355454544" Discharge GW4-20-30 Free Air Volumeft ³ 28.832.235.639.06" Discharge GW6-24-48 Fill Timesec354040406" Discharge GW6-24-48 Free Air Volumeft ³ 28.832.232.633.36" Discharge 10.6 Free Air Volumeft ³ 61.068.375.582.76" Discharge 10.6 Free Air Volumesec354040406" Discharge 10.6 <td>GW2.5-8-24</td> <td>Shot Time</td> <td>sec</td> <td>.08</td> <td>.09</td> <td>.09</td> <td>.09</td>	GW2.5-8-24	Shot Time	sec	.08	.09	.09	.09
0.7 ft. ³ (19 l) Folde kN 1.09 1.23 1.29 1.48 4" Discharge Efficiency lb/t ³ 61 61 58 60 4" Discharge Free Air Volume ft ³ 9.8 11.0 12.0 13.2 GW4-12-28 Fill Time sec 15 15 15 15 Tank Volume is 1.7 ft ³ (49 l) Force lb/f 877 1021 1200 1300 4" Discharge Efficiency lb/f ³ 90 93 100 99 4" Discharge Free Air Volume lb/f ³ 20.0 22.4 24.8 27.0 GW4-16-34 Fill Time sec 13 1.5 1.5 1.5 Tank Volume is 3.5 ft ³ (99 l) Force lb/f 976 1185 1342 1467 4" Discharge Free Air Volume liters 815 912 1008 1104 GW4-20-30 Fill Time sec 35 40 40 40	Tank Volume is	Force	lbf	244	275	288	330
Efficiency lb/ft ³ 61 61 58 60 4" Discharge Free Air Volume ft ³ 9.8 11.0 12.0 13.2 GW4-12-28 Fill Time sec 15 15 15 15 Tank Volume is 1.7 ft ³ (49 l) Force lbf 877 1021 1200 1300 4" Discharge Efficiency lb/ft ³ 9.0 9.3 100 99 4" Discharge Free Air Volume ft ³ 20.0 22.4 24.8 27.0 4" Discharge Free Air Volume ft ³ 20.0 22.4 24.8 27.0 GW4-16-34 Free Air Volume ft ³ 20.0 22.4 24.8 27.0 Tank Volume is 5.0 ft 3 (99 l) Force lb/ft 3.0 53 53 55 GW4-20-30 Efficiency lb/ft 3.1 50 53 54 54 6'' Discharge Free Air Volume ft ³ 28.8 32.2 35.6 <t< td=""><td>0.7 ft³ (19 l)</td><td>Force</td><td>kN</td><td>1.09</td><td>1.23</td><td>1.29</td><td>1.48</td></t<>	0.7 ft ³ (19 l)	Force	kN	1.09	1.23	1.29	1.48
A" Discharge (GW4-12-28)Free Air Volume image: secftil9.811.012.013.2GW4-12-28Fill Timesec15151515Shot Timesec.08.08.08.08.08Tank Volume is 1.7 f3 (49 1)Forcelbf877102112001300ForceRf320.022.424.827.04" Discharge GW4-16-34Free Air Volumeft320.022.424.827.06" Discharge 3.5 ft3 (99 1)Forcelbf97611851515Tank Volume is 3.5 ft3 (99 1)Forcelbf9761185134214674" Discharge GW4-20-30Efficiencylb/ft3505354546" Discharge GW6-24-48Free Air Volumelters815912100811046" Discharge GW6-24-48Free Air Volumeft3374242426" Discharge GW6-30-60Free Air Volumeft31071350145516536" Discharge GW6-30-60Free Air Volumeft361.068.375.582.76" Discharge GW6-30-60Free Air Volumeft412.0212.6014.4814.946.6Timesec.20.21.22.23.237.7Bibr2.6611.414.9414.9414.9414.946.7Discharge 		Efficiency	lb/ft ³	61	61	58	60
4" Discharge Free Air Volume litters 277 311 340 374 GW4-12-28 Fill Time sec 15 15 15 15 15 Tank Volume is 1.7 ft ³ (49 l) Force libf 877 1021 1200 1300 4" Discharge Efficiency lib/ft ³ 90 93 100 99 4" Discharge Free Air Volume lib/ft ³ 90 93 100 99 6W4-16-34 Free Air Volume lib/ft ³ 90 93 15 15 Tank Volume is 3.5 ft ³ (99 l) Free Air Volume sec 13 15 15 15 4" Discharge Efficiency lib/ft ³ 50 53 54 54 6w4-20-30 Free Air Volume ft ³ 28.8 32.2 35.6 39.0 6w4-20-30 Shot Time sec 18 20 21 22 Tank Volume is 5.0 ft ³ (142 l) Force lib/f 1075 1350		Eroo Air Volumo	ft ³	9.8	11.0	12.0	13.2
GW4-12-26 GW4-12-28Fill Timesec151515Shot Timesec.08.08.08.08Tank Volume is 5.7 (49 l)Forcelbf877102112001300Forcelb/R ³ 909310099994" Discharge GW4-16-34Free Air Volumeft ³ 20.022.424.827.0Fill Timesec2535353535Shot Timesec.13.15.15.15Tank Volume is 3.5 ff 3 (99 l)Forcelb/f976118513421467Free Air Volumelb/f ³ 5053545454Forcelb/f ⁴³ 28.832.235.639.0Free Air Volumeliters81591210081104GW4-20-30Free Air Volumesec.18.20.21.22Tank Volume is 5.0 ft ³ (142 l)Forcelb/f1075135014851635GW6-24-48Free Air Volumelb/ft ³ 3742424242GW6-24-48Forcelb/ft ³ 374222.23.23Shot Timesec.20.21.22.23.334.40.42 <t< td=""><td>4" Discharge</td><td>Free All Volume</td><td>liters</td><td>277</td><td>311</td><td>340</td><td>374</td></t<>	4" Discharge	Free All Volume	liters	277	311	340	374
Gwa-12-28 Shot Time sec .08 .08 .08 .08 .08 Tank Volume is 1.7 ft ³ (49 l) Force lbf 877 1021 1200 1300 4" Discharge Efficiency lbf/t ³ 90 93 100 99 4" Discharge Free Air Volume ft ³ 20.0 22.4 24.8 27.0 6w4-16-34 Fill Time sec 25 35 35 35 5 hot Time sec 13 1.15 .15 .15 Tank Volume is 3.5 ft ³ (99 l) Force lbf 976 53 54 54 4" Discharge Free Air Volume liters 815 912 1008 1104 Gw4-20-30 Free Air Volume sec .18 .20 .21 .22 Tank Volume is 5.0 ft ³ (142 l) Force lbf 1075 1350 1485 1635 6" Discharge Fill Time sec .20 .21 .22 .23	CW(4, 4, 2, 20)	Fill Time	sec	15	15	15	15
	GW4-12-28	Shot Time	sec	.08	.08	.08	.08
1.7 ft³ (49 l) Force kN 3.93 4.58 5.38 5.83 4" Discharge Efficiency lb/ft³ 90 93 100 99 4" Discharge $fr³$ 20.0 22.4 24.8 27.0 GW4-16-34 Fill Time sec 25 35 35 35 Tank Volume is Shot Time sec .13 .15 .15 .15 Tank Volume is Force lbf 976 1185 1342 1467 6W4-20-30 Free Air Volume ft³ 28.0 33.2 35.6 39.0 4" Discharge fill Time sec 35 40 40 40 GW4-20-30 Free Air Volume ft³ 28.0 35.0 1485 1635 5.0 ft³ (142 l) Force lbf 1075 1350 1485 1635 6" Discharge Free Air Volume ft³ 61.0 68.3 75.5 82.7 6" Discharge F	Tank Volume is	Force	lbf	877	1021	1200	1300
Efficiencylb/t³9093100994" Discharge GW4-16-34Free Air Volumeft³20.022.424.827.0Free Air VolumeFill TimeSec25353535Shot TimeSec115.15.15.15Tank Volume is 3.5 ft³ (99 l)Forcelbf976118513421467MarkA.345.316.026.586.586.586.58MarkHibr976118513421467MarkBefficiencylb/ft³50535454MarkFree Air Volumeft³28.832.235.639.0GW4-20-30Free Air Volumesec.18.91210081104Fill TimeSec.18.20.21.22.23Tank Volume is 5.0 ft³ (142 l)Forcelbf1075135014851635ForceIb/ft³374242424242GW6-24-48Free Air Volumesec.20.21.22.23Tank Volume is 10.6 ft³ (299 l)Forcelb/ft³41434040Free Air VolumeSec.20.21.22.23.23.333Tank Volume is 10.6 ft³ (299 l)Forcelb/ft³131.3147.0162.4178.0GW6-24-48Free Air VolumeSec.20.21.22.23.23.333Tan	1.7 ft ³ (49 l)	Force	kN	3.93	4.58	5.38	5.83
A" Discharge GW4-16-34Free Air Volumeft³20.022.424.827.0GW4-16-34Fill TimeSec566634702765Shot TimeSec25353535Tank Volume is 3.5 ft³ (99 l)ForceIbf976118513421467Fill CincyIb/t³5053545454MarceEfficiencyIb/t³50535454MarceFree Air Volumeft³28.832.235.639.0Fill TimeSec35404040GW4-20-30Fill TimeSec35404040Shot TimeSec3540404040Shot TimeSec3544.0404040GW4-20-30ForceIb/f³1075135014851635Shot TimeSec3544.0404040GW6-24-48ForceIb/f³37424242GW6-24-48Fill TimeSec909090105Shot TimeSec.20.21.22.23.23Tank Volume is 10.6 ft³ (299)ForceIb/f³44414340GW6-30-60Fill TimeSec.38.40.42.44GW6-30-60Fill TimeSec.38.40.42.44Tank Volume is 2. Shot TimeSec.38		Efficiency	lb/ft ³	90	93	100	99
4" Discharge Iftee Air Volume liters 566 634 702 765 GW4-16-34 Fill Time sec 25 35 35 35 Tank Volume is 3.5 ft ³ (99 l) Force lbf 976 1185 1342 1467 A" Discharge Efficiency lb/ft ³ 50 53 54 54 GW4-20-30 Free Air Volume ft ³ 28.8 32.2 35.6 39.0 Tank Volume is 5.0 ft ³ (142 l) Free Air Volume sec 35 40 40 40 Time sec .18 .20 .21 .22 .22 Tank Volume is 5.0 ft ³ (142 l) Force lbf 1075 1350 1485 1635 GW6-24-48 Free Air Volume sec 90 90 90 105 Shot Time sec .20 .21 .22 .23 .23 GW6-24-48 Free Air Volume sec .20 .21 .22 .23		Eroo Air Volumo	ft ³	20.0	22.4	24.8	27.0
GW4-16-34 Fill Time sec 25 35 35 35 Tank Volume is 3.5 ft³ (99 l) Force Ibf 976 1185 1342 1467 A" Discharge Efficiency Ib/ft³ 50 53 54 54 A" Discharge $ft³$ 28.8 32.2 35.6 39.0 GW4-20-30 Free Air Volume ft³ 28.8 32.2 35.6 39.0 Tank Volume is 5.0 ft³ (142 l) Free Air Volume ft³ 28.8 32.2 35.6 39.0 Force Ib/ft 1075 1350 1085 1040 40 GW4-20-30 Force Ib/f 1075 1350 1485 1635 Shot Time sec .18 .20 .21 .22 Tank Volume is 5.0 ft³ (142 l) Force ft³ 61.0 68.3 75.5 82.7 GW6-24-48 Fill Time sec 90 90 90 105 Shot Time sec	4" Discharge		liters	566	634	702	765
GW4-10-34 Shot Time sec .13 .15 .15 .15 Tank Volume is 3.5 ft³ (99 i) Force lbf 976 1185 1342 1467 4" Discharge Efficiency lb/t³ 50 53 54 54 6W4-20-30 Free Air Volume ft³ 28.8 32.2 35.6 39.0 7ank Volume is 5.0 ft³ (142 l) Free Air Volume sec .18 .20 .21 .22 7ank Volume is 5.0 ft³ (142 l) Force lbf 1075 1350 1485 1635 6" Discharge Free Air Volume ft³ 61.0 68.3 75.5 82.7 6" Discharge Free Air Volume ft³ 61.0 68.3 75.5 82.7 6" Discharge Fill Time sec 90 90 90 90 90 90 6" Discharge Fill Time sec .20 .21 .22 .23 Tank Volume is 10.6 ft³ (299 l) Force lbf 26	CW/4 1 C 24	Fill Time	sec	25	35	35	35
$ \begin{array}{c c c c c c c c } \hline \mbox{Tank Volume is} \\ 3.5 \mbox{ft}^3 (99 l) & Force & libf & 976 & 1185 & 1342 & 1467 \\ \hline \mbox{kN} & 4.34 & 5.31 & 6.02 & 6.58 \\ \hline \mbox{Efficiency} & lb/ft^3 & 50 & 53 & 54 & 54 \\ \hline \mbox{Efficiency} & lb/ft^3 & 50 & 53 & 54 & 54 \\ \hline \mbox{Free Air Volume} & frad & 28.8 & 32.2 & 35.6 & 39.0 \\ \hline \mbox{Itree Air Volume} & frad & 815 & 912 & 1008 & 1104 \\ \hline \mbox{Fill Time} & sec & 35 & 40 & 40 & 40 \\ \hline \mbox{Shot Time} & sec & .18 & .20 & .21 & .22 \\ \hline \mbox{Tank Volume is} & 5.0 \mbox{ft}^3 (142 \ l) & Force & lbf & 1075 & 1350 & 1485 & 1635 \\ \hline \mbox{Free Air Volume} & lb/ft^3 & 37 & 42 & 42 & 42 \\ \hline \mbox{Fficiency} & lb/ft^3 & 37 & 42 & 42 & 42 \\ \hline \mbox{Fficiency} & lb/ft^3 & 37 & 42 & 42 & 42 \\ \hline \mbox{Free Air Volume} & frad & 61.0 & 68.3 & 75.5 & 82.7 \\ \hline \mbox{Free Air Volume} & sec & .20 & .21 & .22 & .23 \\ \hline \mbox{Free Air Volume} & sec & .20 & .21 & .22 & .23 \\ \hline \mbox{Free Air Volume} & sec & .20 & .21 & .22 & .23 \\ \hline \mbox{Free Air Volume} & sec & .20 & .21 & .22 & .23 \\ \hline \mbox{Force} & lbf & 2681 & 2812 & 3230 & 3333 \\ \hline \mbox{Force} & lbf & 2681 & 2812 & 3230 & 3333 \\ \hline \mbox{Force} & lbf & 2681 & 2812 & 3230 & 3333 \\ \hline \mbox{Force} & lbf & 2681 & 2812 & 3230 & 3333 \\ \hline \mbox{Force} & lbf & 2681 & 2812 & 3230 & 3333 \\ \hline \mbox{Force} & lbf & 2681 & 2812 & 3230 & 3333 \\ \hline \mbox{Force} & lbf & 2681 & 2812 & 3230 & 3333 \\ \hline \mbox{Free Air Volume} & frad & 11.0 & 162.4 & 178.0 \\ \hline \mbox{Free Air Volume} & frad & 131.3 & 147.0 & 162.4 & 178.0 \\ \hline \mbox{Free Air Volume} & frad & 311.3 & 147.0 & 162.4 & 178.0 \\ \hline \mbox{Free Air Volume} & sec & .38 & .40 & .42 & .44 \\ \hline \mbox{Free Air Volume} & sec & .38 & .40 & .42 & .44 \\ \hline \mbox{Free Air Volume} & litters & 3718 & 4162 & 4599 & 5040 \\ \hline \mbox{Free Air Volume} & frad & 3190 & 3345 & 3840 & 3965 \\ \hline \mbox{Force} & kN & 14.30 & 14.99 & 17.21 & 17.77 \\ \hline \mbox{Fficiency} & lb/ft^3 & 24 & 23 & 24 & 22 \\ \hline \mbox{Free Air Volume} & lbf & 3190 & 3345 & 3840 & 3965 \\ \hline \mbox{Free Air Volume} & lbf & 3190 & 3345 & 3840 & 3965 \\ \hline \m$	GW4-16-34	Shot Time	sec	.13	.15	.15	.15
3.5 ft ³ (99 l) Free Indice kN 4.34 5.31 6.02 6.58 4" Discharge Free Air Volume ft ³ 50 53 54 54 6W4-20-30 Free Air Volume ft ³ 28.8 32.2 35.6 39.0 Tank Volume is 5.0 ft ³ (142 l) Free Air Volume sec 35 40 40 40 Free Air Volume force lbf 1075 1350 1485 1635 6" Discharge Free Air Volume lbf 1075 1350 1485 1635 6" Discharge Free Air Volume lbf 1077 1934 2138 2342 6" Discharge Free Air Volume sec .20 .21 .22 .23 GW6-24-48 Force lbf 2681 2812 3230 3333 10.6 ft ³ (299 l) Force kN 4.20 .21 .22 .23 6" Discharge Free Air Volume ft ³ 131.3 147.0 162.4 178.0 6" Discharge Free Air Volume ft ³	Tank Volume is	Forco	lbf	976	1185	1342	1467
Efficiency lb/ft ³ 50 53 54 54 4" Discharge $Free Air Volume$ ft^3 28.8 32.2 35.6 39.0 GW4-20-30 Fill Time 815 912 1008 1104 GW4-20-30 Fill Time sec 35 40 40 40 Tank Volume is $50 t$ Time sec .18 .20 .21 .22 Tank Volume is $Force$ lbf 1075 1350 1485 1635 6" Discharge $Free Air Volume$ lbft ³ 37 42 42 42 6" Discharge $Free Air Volume$ ftf ³ 61.0 68.3 75.5 82.7 6" Discharge Fill Time sec 90 90 105 333 10.6 ft ³ (299 l) Force lbf 2681 2812 3230 3333 10.6 ft ³ (299 l) Force lbf 181.3 147.0 162.4 178.0 6" Discharge <t< td=""><td>3.5 ft³ (99 l)</td><td>TOICE</td><td>kN</td><td>4.34</td><td>5.31</td><td>6.02</td><td>6.58</td></t<>	3.5 ft ³ (99 l)	TOICE	kN	4.34	5.31	6.02	6.58
A" Discharge $Free Air Volume$ ft^3 28.8 32.2 35.6 39.0 GW4-20-30 Fill Time sec 35.6 40 40 Shot Time sec 35.6 40 40 40 Tank Volume is 5.0 ft^3 (142 l) $Force$ $llof$ 1075 1350 1485 1635 G" Discharge $Free Air Volume$ $llof t^3$ 37.42 42.4 42.4 G" Discharge $Free Air Volume$ ft^3 61.0 68.3 75.5 82.7 G" Discharge $Free Air Volume$ ft^3 61.0 68.3 75.5 82.7 G" Discharge $Free Air Volume$ ft^3 61.0 68.3 75.5 82.7 Gw6-24-48 Free Air Volume sec 90 90 90 90 105 Shot Time sec 20 211 222 233 3333 Tank Volume is 10.6 11617		Efficiency	lb/ft ³	50	53	54	54
4" Discharge Inter Air Volume liters 815 912 1008 1104 GW4-20-30 Fill Time sec 35 40 40 40 Shot Time sec .18 .20 .21 .22 Tank Volume is 5.0 ft ³ (142 l) Force lbf 1075 1350 1485 1635 6" Discharge Efficiency lb/ft ³ 37 42 42 42 6" Discharge Free Air Volume ft ³ 61.0 68.3 75.5 82.7 6" Discharge Free Air Volume ft ³ 61.0 68.3 75.5 82.7 6" Discharge Free Air Volume sec 90 90 90 105 Shot Time sec .20 .21 .22 .23 Tank Volume is 10.6 ft ³ (299 l) Force lbf 2681 2812 3230 3333 6" Discharge Free Air Volume ft ³ 131.3 147.0 162.4 178.0		Free Air Volume	ft ³	28.8	32.2	35.6	39.0
GW4-20-30 Fill Time sec 35 40 40 40 Shot Time sec .18 .20 .21 .22 Tank Volume is 5.0 ft ³ (142 l) $Porce$ lbf 1075 1350 1485 1635 Efficiency lbft ³ 37 42 42 42 Efficiency lbft ³ 37 42 42 42 Free Air Volume ft ³ 61.0 68.3 75.5 82.7 GW6-24-48 Fill Time sec 90 90 90 105 Shot Time sec .20 .21 .22 .23 Tank Volume is 10.6 ft ³ (299 l) Force lbf 2681 2812 3230 3333 6" Discharge Free Air Volume ft ³ 131.3 147.0 162.4 178.0 6" Discharge Fill Time sec .210 .210 .210 .210 GW6-30-60 Fill Time sec .38 .40 <td.< td=""><td>4" Discharge</td><td>liters</td><td>815</td><td>912</td><td>1008</td><td>1104</td></td.<>	4" Discharge		liters	815	912	1008	1104
Gw4-20-30 Shot Time sec .18 .20 .21 .22 Tank Volume is 5.0 ft ³ (142 l) $Force$ lbf 1075 1350 1485 1635 Force kN 4.82 6.05 6.66 7.33 Efficiency lb/ft ³ 37 42 42 42 6" Discharge Free Air Volume ft ³ 61.0 68.3 75.5 82.7 Gw6-24-48 Fill Time sec 90 90 90 105 Shot Time sec .20 .21 .22 .23 Tank Volume is 10.6 ft ³ (299 l) Force lbf 2681 2812 3230 3333 Force lbf 2681 2812 3230 3333 6" Discharge Free Air Volume ft ³ 131.3 147.0 162.4 178.0 6" Discharge Free Air Volume ft ³ 131.3 147.0 162.4 178.0 Gw6-30-60 Fill Time sec <	CW/4 20 20	Fill Time	sec	35	40	40	40
$ \frac{ \mbox{Tank Volume is} \ 5.0 \mbox{ft}^3 (142 \mbox{l}) \ }{ \mbox{Free Air Volume} } \frac{ \mbox{lbft}^3 \ 1075 \ 1350 \ 1485 \ 1635 \ }{ \mbox{lbft}^3 \ 1635 \ } \ \\ \frac{ \mbox{Free Air Volume} \ }{ \mbox{Free Air Volume} \ } \frac{ \mbox{ft}^3 \ 61.0 \ 68.3 \ 75.5 \ 82.7 \ }{ \mbox{liters} \ 1727 \ 1934 \ 2138 \ 2342 \ } \ \\ \frac{ \mbox{Free Air Volume} \ }{ \mbox{Fill Time} \ } \frac{ \mbox{ft}^3 \ 61.0 \ 68.3 \ 75.5 \ 82.7 \ }{ \mbox{liters} \ 1727 \ 1934 \ 2138 \ 2342 \ } \ \\ \frac{ \mbox{Fill Time} \ 5ec \ 90 \ 90 \ 90 \ 90 \ 90 \ 105 \ }{ \mbox{Shot Time} \ 5ec \ 200 \ 201 \ 210 \ 220 \ } \ \\ \frac{ \mbox{Free Air Volume} \ }{ \mbox{Free Air Volume} \ } \frac{ \mbox{lbft}^3 \ 2681 \ 2812 \ 3230 \ 3333 \ }{ \mbox{3333} \ } \ \\ \frac{ \mbox{Free Air Volume} \ }{ \mbox{Free Air Volume} \ } \frac{ \mbox{lbft}^3 \ 444 \ 41 \ 43 \ 40 \ 14.48 \ 14.94 \ }{ \mbox{44} \ 41 \ 43 \ 40 \ } \ \\ \frac{ \mbox{Free Air Volume} \ }{ \mbox{Free Air Volume} \ } \ \\ \frac{ \mbox{Free Air Volume} \ }{ \mbox{Free Air Volume} \ } \frac{ \mbox{ft}^3 \ 131.3 \ 147.0 \ 162.4 \ 178.0 \ }{ \mbox{14.48} \ 14.94 \ }{ \mbox{44} \ 41 \ 43 \ 40 \ } \ \\ \frac{ \mbox{Free Air Volume} \ }{ \mbox{Free Air Volume} \ } \ \\ \frac{ \mbox{Free Air Volume} \ }{ \mbox{Free Air Volume} \ } \ \\ \frac{ \mbox{ft}^3 \ 131.3 \ 147.0 \ 162.4 \ 178.0 \ }{ \mbox{14.48} \ 14.94 \ }{ \mbox{44} \ } \ \\ \frac{ \mbox{Free Air Volume} \ }{ \mbox{Free Air Volume} \ } \ \\ \frac{ \mbox{ft}^3 \ 131.3 \ 147.0 \ 210 \$	GW4-20-30	Shot Time	sec	.18	.20	.21	.22
5.0 ft ³ (142 l) Horce kN 4.82 6.05 6.66 7.33 Efficiency lb/ft ³ 37 42 42 42 6" Discharge $Free Air Volume$ ft ³ 61.0 68.3 75.5 82.7 6" Discharge Fill Time sec 90 90 90 105 GW6-24-48 Fill Time sec 20 .21 .22 .23 Tank Volume is 10.6 ft ³ (299 l) Force lbf 2681 2812 3230 3333 6" Discharge Free Air Volume lb/ft ³ 44 41 43 40 6" Discharge Free Air Volume lb/ft ³ 144 41 43 40 6" Discharge Free Air Volume lb/ft ³ 144 41 43 40 6" Discharge Free Air Volume liters 3718 4162 4599 5040 GW6-30-60 Fill Time sec .38 .40 .42 .44 Tank Volume is 2.8 ft ³ (645 l) Force lb/ft 3190 3345 3840 <td>Tank Volume is</td> <td rowspan="2">Force</td> <td>lbf</td> <td>1075</td> <td>1350</td> <td>1485</td> <td>1635</td>	Tank Volume is	Force	lbf	1075	1350	1485	1635
Efficiency lb/ft ³ 37 42 42 42 6" Discharge $Free Air Volume$ ft^3 61.0 68.3 75.5 82.7 6" Discharge Frill Time sec 90 90 2138 2342 GW6-24-48 Fill Time sec 90 90 90 105 Tank Volume is 10.6 ft ³ (299 l) Force Ibf 2681 2812 3230 3333 ft^3 (299 l) Force Ibf 2681 2812 3230 3333 ft^3 (299 l) Force Ib/ft ³ 44 41 43 40 ft Efficiency Ib/ft ³ 44 41 43 40 ft Efficiency Ib/ft ³ 44 41 43 40 ft Efficiency Ib/ft ³ 131.3 147.0 162.4 178.0 ft Time sec 318 4162 4599 <t< td=""><td>5.0 ft³ (142 l)</td><td>kN</td><td>4.82</td><td>6.05</td><td>6.66</td><td>7.33</td></t<>	5.0 ft ³ (142 l)		kN	4.82	6.05	6.66	7.33
6" Discharge $Free Air Volume$ ft^3 61.0 68.3 75.5 82.7 GW6-24-48 Fill Time sec 90 90 90 105 Shot Time sec 90 90 90 105 Tank Volume is 10.6 ft ³ (299 l) Force Ibf 2681 2812 3230 3333 Force Ibf 2681 2812 3230 3333 3333 6" Discharge Force Ibf 2681 2812 3230 3333 6" Discharge Free Air Volume Ibf 313.3 147.0 162.4 178.0 GW6-30-60 Free Air Volume sec 210 210 210 210 Tank Volume is Shot Time sec 318 4162 4599 5040 Tank Volume is Force Ibf 3190 3345 3840 3965 Shot Time Efficiency Ibf 3190 3345 3840 3965 KN		Efficiency	lb/ft ³	37	42	42	42
6" Discharge Inter Air Volume liters 1727 1934 2138 2342 GW6-24-48 Fill Time sec 90 90 90 105 Tank Volume is 10.6 ft ³ (299 l) Force Ibf 2681 2812 3230 3333 Force Ibf 318.0 14.00 14.48 14.94 Free Air Volume Iters 3718 4162 4599 5040 GW6-30-60 Fill Time sec 210 210 210 210 210 Tank Volume is 22.8 ft ³ (645 l) Force Ibf 3190 3345 3840 3965 Efficiency Ib/ft ³ 24 23 24 22 <td></td> <td>Froo Air Volumo</td> <td>ft³</td> <td>61.0</td> <td>68.3</td> <td>75.5</td> <td>82.7</td>		Froo Air Volumo	ft ³	61.0	68.3	75.5	82.7
GW6-24-48 Fill Time sec 90 90 90 105 Tank Volume is 10.6 ft ³ (299 l) Shot Time sec .20 .21 .22 .23 Force Ibf 2681 2812 3230 3333 Efficiency Ibf 12.02 12.60 14.48 14.94 Force Ib/ft ³ 44 41 43 40 Free Air Volume Iters 3718 147.0 162.4 178.0 Fill Time sec 210 210 210 210 210 GW6-30-60 Fill Time sec 210 210 210 210 Tank Volume is Shot Time sec .38 .40 .42 .44 Tank Volume is Force Ibf 3190 3345 3840 3965 2.8 ft ³ (645 l) Efficiency Ib/ft ³ 24 23 24 22	6" Discharge		liters	1727	1934	2138	2342
Gwo-24-48 Shot Time sec .20 .21 .22 .23 Tank Volume is 10.6 ft ³ (299 l) $Force$ Ibf 2681 2812 3230 3333 More ft ³ (299 l) $Force$ Ibf 2681 2812 3230 3333 Image ft $Force$ Ibf 2681 2812 3230 3333 Image ft $Force$ Ibf 2681 2812 3230 3333 Image ft $Force$ Ibf 12.02 12.60 14.48 14.94 Image ft Ibf 313.3 147.0 162.4 178.0 Image ft Free Air Volume Iters 3718 4162 4599 5040 Image ft Image ft Shot Time Secc 318 .40 .42 .44 Image ft Image ft Force Image ft Image ft Image ft Image ft Image	CW6 24 49	Fill Time	sec	90	90	90	105
$ \begin{array}{c c c c c c c c c c c c c c c c c c c $	GW0-24-48	Shot Time	sec	.20	.21	.22	.23
$ \begin{array}{c c c c c c c c c c c c c c c c c c c $	Tank Volume is	Force	lbf	2681	2812	3230	3333
Efficiency lb/ft ³ 44 41 43 40 6" Discharge $Free Air Volume$ ft^3 131.3 147.0 162.4 178.0 6" Discharge $Free Air Volume$ $liters$ 3718 4162 4599 5040 6W6-30-60 Fill Time sec 210 210 210 210 Tank Volume is Shot Time sec .38 .40 .42 .44 Tank Volume is $Force$ lbf 3190 3345 3840 3965 $Efficiency$ lb/ft^3 24 23 24 22	10.6 ft ³ (299 l)	Force	kN	12.02	12.60	14.48	14.94
6" Discharge Free Air Volume ft^3 131.3 147.0 162.4 178.0 6" Discharge Free Air Volume liters 3718 4162 4599 5040 GW6-30-60 Fill Time sec 210 210 210 210 210 Tank Volume is 22.8 ft ³ (645 l) Force Ibf 3190 3345 3840 3965 Efficiency Ib/ft ³ 24 23 24 22		Efficiency	lb/ft ³	44	41	43	40
6" Discharge Hee All Volume liters 3718 4162 4599 5040 GW6-30-60 Fill Time sec 210 210 210 210 210 Shot Time sec .38 .40 .42 .44 Tank Volume is 22.8 ft ³ (645 l) Force Ibf 3190 3345 3840 3965 Efficiency Ib/ft ³ 24 23 24 22		Free Air Volumo	ft ³	131.3	147.0	162.4	178.0
GW6-30-60 Fill Time sec 210 210 210 210 Shot Time sec .38 .40 .42 .44 Tank Volume is 22.8 ft ³ (645 l) Force lbf 3190 3345 3840 3965 Efficiency lb/ft ³ 24 23 24 22	6" Discharge		liters	3718	4162	4599	5040
Gwo-so-oo Shot Time sec .38 .40 .42 .44 Tank Volume is 22.8 ft ³ (645 l) Force lbf 3190 3345 3840 3965 Efficiency lb/ft ³ 24 23 24 22	-	Fill Time	sec	210	210	210	210
Tank Volume is 22.8 ft ³ (645 l) Force lbf 3190 3345 3840 3965 Efficiency lb/ft ³ 24 23 24 22	GM0-30-60	Shot Time	sec	.38	.40	.42	.44
22.8 ft ³ (645 l) Force kN 14.30 14.99 17.21 17.77 Efficiency lb/ft ³ 24 23 24 22	Tank Volume is	Forco	lbf	3190	3345	3840	3965
Efficiency Ib/ft ³ 24 23 24 22	22.8 ft ³ (645 l)		kN	14.30	14.99	17.21	17.77
		Efficiency	lb/ft ³	24	23	24	22

FORCE measurements were made using an 8" diameter, 1" thick piston, located 4" from the Air Blaster discharge mount flange, to transfer the blast impulse to a dynamic sensor. A 1" solenoid valve, without muffler, mounted directly to the air inlet port was used to fire the GW4 and GW6 model Air Blasters. A 3/4" solenoid was used for the GW2.5 model.

FILL TIME, SHOT TIME, & FORCE for the GW6-30-60 were not measured. The data presented is an estimation of performance for this model. The force output is too powerful for the dynamic sensor.



Appendix F - Parts Drawings



	Parts List for GW2.5-8-24 Air Blaster - pn 802024										
#	Description	Part #	Qty	#	Description	Part #	Qty				
1	Bolt Hex ⁵ /8" - 11 x ³ /4" GR5	331517	4	11	*Valve Cap	304225	1				
2	Washer Lock 5/8"	338110	4	12	*O-Ring BUNA 568-324	385324	1				
3	Coupling	300125	1	13	*O-Ring BUNA 568-112	385112	1				
4	Gasket	296125	1	14	*Retaining Ring 5000-250	347250	1				
5	Valve Assembly*	305725	1	15	Fill Line 1/2"	260071	1				
6	*Valve Body	302525	1	16	Plug, Solid 1/2"	295108	1				
7	*0-Ring BUNA 568-228	385228	1	17	Tank	305224	1				
8	*Valve Seat	304625	1	18	Valve Pressure Relief ¹ /2"	290408	1				
9	*Piston	275725	1	19	Bushing 2" x ³ /4" x ³ /4"	295432	1				
10	*O-Ring BUNA 568-331	385331	2	*	Parts in Valve Assembly	305725	1				



Parts List for GW4" Air Blaster Models

GW4-12-28 pn 804028 / GW4-16-34 pn 804029 / GW4-20-30 pn 804030

#	Description	Part #	Qty	#	Description	Part #	Qty
1	Hex Bolt ⁵ /8"- 11 x 1 ³ /4" GR5	331517	8	14	*0-Ring BUNA 568-331	385331	1
2	Lock Washer ⁵ /8"	338110	8	15	*0-Ring BUNA 568-118	385118	1
3	Coupling	300140	1	16	*Retaining Ring 5000-400	347400	1
4	Gasket	296140	1	17	Solid Plug 1/2"	295108	2
5	Valve Assembly*	305740	1	18	Tank 4-12-28	306428	1
6	*Valve Body	302540	1	18	Tank 4-16-34	306434	1
7	*0-Ring BUNA 568-240	385240	1	18	Tank 4-20-30	307430	1
8	*Valve Seat	304640	1	19	Pressure Relief Valve 1/2"	290408	1
9	*O-Ring Viton 568-237	386237	1	20	Fill line ³ / ₄ " - 4-12-28	260073	1
10	*Piston	275740	1	20	Fill line ³ / ₄ " - 4-16-34	260075	1
11	*O-Ring Viton 568-208	386208	1	20	Fill line ³ / ₄ " - 4-20-30	260074	1
12	*O-Ring BUNA 568-343	385343	2	21	Bushing 2" x 1" x 1"	295434	1
13	*Valve Cap	304240	1	22	Bushing 1" x ³ / ₄ "	295416	1



Parts List for GW6" Air Blaster Models

GW6-24-48 pn 806048

GW6-30-60 pn 806060

	Description	Part	Qty	#	Description	Part #	Qty
1	Hex Bolt ³ / ₄ "- 10 x 2" GR5	331517	8	13	*Valve Cap	304260	1
2	Lock Washer ³ /4"	338112	8	14	*0-Ring BUNA 568-343	385343	1
3	Coupling	300160	1	15	*0-Ring BUNA 568-122	385122	1
4	Gasket	296160	1	16	*Retaining Ring 5000-625	347625	1
5	Valve Assembly	305760	1	17	Solid Plug 1/2"	295108	2
6	*Valve Body	302560	1	18	Tank - 6-24-48	307648	1
7	*0-Ring BUNA 568-431	385431	1	18	Tank - 6-30-60	307660	1
8	*Valve Seat	304660	1	19	Pressure Relief Valve 1/2"	290408	1
9	*O-Ring Viton 568-254	386254	1	20	Plug - Black Cast 2"	295232	1
10	*Piston	275760	1	21	Fill line 1" - 6-24-48	260076	1
11	*O-Ring BUNA 568-212	385212	1	21	Fill line 1" - 6-30-60	260077	1
12	*O-Ring BUNA 568-436	385436	2	22	Bushing 2 x 1 x 1"	295434	1



Coordinates and Dimensions of Elliptical Openings for Tangential Mount - Dimensions in Inches									
	2.5" Pipe 4" Pipe 6" Pipe								
	X	Y	X	X Y		Y			
Α	-1.46	.53	-2.21	.81	-3.39	1.23			
В	1.20	3.29	1.55	4.26	2.46	6.75			
С	1.46	53	2.21	81	3.39	-1.23			
D	-1.20	-3.29	-1.55	-7.26	-2.46	-6.75			
Width		3.07	4.70 7.21						
Height	7	7.00	9.07 14.37						